

Mammoth Designs

Instructions for Installation and Care of Arctic Cat Prowler Mini Cab Enclosure

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before unrolling and installing the Mammoth Designs Cab Enclosure. The installation is best done when the temperature is 65 degrees F. or warmer.
2. Carefully unroll the Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab. Next Open the hood compartment and raise the bed. This will allow access to front and rear to install the necessary Velcro pieces.
3. Check over the parts included in the carton with the parts list shown below:

Self Adhesive Velcro Hook strips:	6 each	10" long
" "	2 each	24" long
" "	2 each	5" long
Cab Enclosure	1 each	
4. Loosely drape the Cab Enclosure over the Prowler roll cage, making sure to pass the rear brake light through the hole in the rear of the enclosure. Note the correct position for the 24" Velcro Hook strips along the bottom of the Windshield. **Clean the area with Isopropyl alcohol**, let dry and apply the Velcro hook strip. The Velcro strips should be along the area that is under the Hood when it is closed.



5. Working your way to the rear of the roll cage, carefully fit the Cab into position. Be sure to pull the lower edge of the rear panel down between the rear of the roll cage and the front of the dump bed. Apply the two 5" and two 10" Velcro hook strips on the back of the roll cage at the side where you see a tab is going to wrapping around to the back of the cage. Be certain to clean the surfaces before applying the adhesive loop strips!



6. Take note of the position of the two 10" Loop Tabs that are on both sides of the windshield. Apply the corresponding Velcro hook strips to these locations. Making sure to clean the area first.
7. Now close the front hood and secure it down. It should sit on top of the bottom of the windshield. Then lower the bed into position and the bed will push in on the back of the enclosure. If it seems too tight across the rear panel, you can adjust the distance by loosening the rear panel and repositioning the Velcro a bit.

Cleaning and Storage Recommendations:

1. Before removing the Mammoth Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge (I recommend a flannel or Micro Fiber Cloths) using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.